



EXHAUST GAS TEMPERATURE/CYLINDER HEAD TEMPERATURE

Illustration of Instrument Connection:



NOTE:

- 1) When installing the instrument from behind the panel use a $2\frac{1}{4}$ " hole. When installing the unit from in front of the panel use a $2\frac{1}{16}$ " hole. Use 4-"40 screws to hold instrument secure.